

## DELAVAL NOZZLE BAR INSTALLATION INSTRUCTIONS

- DK**
- Start med at rengøre gulvet og risten i robotten grundigt, rengør også under gummimåtten.
  - Fastgør dysepladens monteringsbolte<sup>1</sup> i eksisterende huller på bagpladen i robotten som illustreret. Eksisterende bolte skal afmonteres først.
  - Tilslut kemi leveringslangen til dysepladens blå 6/4 mm push-on kobling<sup>2</sup>, inden dysepladen endeligt fastgøres. Den blå omløber skal tilspændes med håndkraft.
  - Monter dysepladen, som illustreret, med de to medfølgende M8x16 mm bolte og pynteskiver<sup>3</sup>.
  - Det er vigtigt at dysepladen er i vatter.
  - Tilslut den sorte 16/13 mm PA slange på den blå 12 mm slangestuds, benyt det medfølgende 8-16 mm spændebånd
  - Tilslut herefter de to slanger til henholdsvis Controller'en og doseringspumpen.
  - Slut af med at indstille dyserne, hvis dette er nødvendigt.
- UK**
- First, clean the robot floor and grate thoroughly, even under the rubber mat.
  - Attach the nozzle bar mounting bolt kit<sup>1</sup> in existing holes on the robot back plate as illustrated. The existing bolt must be removed first.
  - When the mounting bolt kit is secured, connect the 6/4 mm disinfectant delivery tube to the nozzle bar blue push-on connector<sup>2</sup>. Tighten the blue nut firmly by hand.
  - Install the nozzle bar as illustrated, using the two included M8x16 mm bolts and finishing washers<sup>3</sup>.
  - It is important that the nozzle bar is leveled.
  - Connect the black 16/13 mm PA tube to the 12 mm hose stud, use the supplied 8-16 mm hose clamp
  - Connect the two tubes respectively to the Controller and the peristaltic pump.
  - If necessary, finish by adjusting the nozzles. Use the test function to check spray pattern.

## DELAVAL NOZZLE BAR.

